

ABOUT US



Founded in 1967 by Sir Graeme Douglas, Douglas Pharmaceuticals Ltd is one of the fastest growing pharmaceutical companies in Oceania. Outstanding customer service and the highest manufacturing standards have driven the company's success. Douglas is consistently ranked as the top performer in New Zealand Coal Face Surveys on customer satisfaction.

Douglas Pharmaceuticals is currently enjoying significant growth as it expands to meet international demand. The company prides itself on being leading edge in every aspect of the business and in 2014 established an Automation Division to assist pharmacy to be both more efficient in dispensing prescription drugs and more profitable as a business. The Douglas Automation products are transforming the way dispensary operates in today's competitive market.

yuyama

Yuyama was founded in 1964 in Osaka, Japan and specialises in medical and pharmaceutical automation. Yuyama is the world's largest manufacturer of pharmacy automation equipment.

Driven by innovation, Yuyama machines have proven to be exceptionally reliable, user-friendly, fast and safe. Recognised for superior service, Yuyama is a market leader in the evolution of pharmacy automation. Yuyama has worldwide operations in the USA, Japan, EU, Korea, China, Taiwan, and Saudi Arabia. Its US Division has over 2200 machines dispensing medications daily.





This is what you have been asking for - a safe, fast, accurate and reliable dispensing machine that is easy to run and feels like a hard-working member of your team. Alpaca makes your pharmacy business run more efficiently, and allows more time to focus on improving the health outcomes of your customers, young and old.



ALPACA PACK FASTER THAN YOU CAN



"Scan, pack, seal, it is that fast and that simple" - Antony, Life Pharmacy Orewa

The Alpaca will free up your staff to do more productive duties. Why do Medico Paks in advance when the Alpaca is so fast you can make packs for that day at the time the patient presents a script.

Output (On Average)

- 1.5 to 3 minutes per Medico Pak including manual fills
- Between 30 to 40 packs per hour depending on complexity of manual fills

Semi Automated Robot

- The Alpaca makes faster, more accurate and safer Medico Paks
- The Alpaca will reduce the time your staff spends on making Medico Paks allowing them to focus on increasing your Medico sales through consulting with your community patients
- The Alpaca uses blister technology similar to Medico which is fully compliant with the Ministry of Health regulations and has 4 weeks stability data

Your Package

1 x Alpaca Robot 1 x High Speed Printer

1 x Touch Screen Bundle1 x Embedded Server Bundle1 x UPS Bundle1 x Riser & Restraint Bundle

120 x Calibrated Canisters

300 x Cold Seal & Blisters

1 x Platten

Installation of the Alpaca takes 3-4 days, including onsite training for up to 4 staff. Ongoing training support can also be provided.





ALPACA LOT MORE IN A DAY



"What was taking all day to do, is now completed before morning tea."

Samantha, Life Pharmacy Orewa

The Alpaca can assemble Medico Paks from both LOTS and Toniq pharmacy dispensing systems. It comes with barcode technology to verify the correct prescription foil is matched with the correct dispensed blister. The barcode technology enables high level safety checks to avoid medication errors during refilling of the canisters and manual fills.

One of the reasons the Alpaca is so fast is its ability to process the next script while you have the drawer open sealing your current Medico Pak. Once the drawer is closed the next script is ready to be packed/sealed. In this way volumes of 20, 30, or 40 packs an hour can be achieved.

The daily dispensary task of making Medico Paks will no longer consume large numbers of staff and time, potentially reducing costs by 50% to 85%. One staff member's output, operating an Alpaca, may increase productivity from 35/50 packs per day to potentially 320 packs per day (40 x 8 hours).

The Alpaca comes with 120 calibrated canisters which are tailored specifically for the needs/demand of the individual pharmacy.

Offers

- Full Blister Pack Dispensing
- Full Computer Inventory System
- Dispensing History
- Dispensing Reports







ALPACA FEATURES & BENEFITS



Embedded Server

- *Software runs faster
- · Backups are automated
- *More reliable hardware
- *Integrates better with your pharmacy network
- Increased remote diagnostics
- Can control from existing pharmacy PC instead of touch screen (to operate Toniq & Alpaca from one PC)
- Full compatibility with Douglas hardware/software "add-ons"
- Integrated print server allowing drivers/settings to be managed on the Alpaca

*When compared against the Alpaca 1.0

Riser & Restraint

- Raises the Alpaca drawer to 95cm
- The Riser bolts securely to the Alpaca
- Extended rear protects power cable damage & preserves ventilation
- Lockable levelling casters
- Docking bracket bolts securely to the floor and/or wall
- The Alpaca undocks from the bracket by pulling on the lever for easy servicing

UPS (Power Stabiliser & Backup Battery)

- Surge protection
- Stabilises power fluctuations
- Fully integrates with the Alpaca
- Runs for 5 minutes in a power cut before safely shutting down preventing data loss
- Automatically turns back on when the power is restored

Touch Monitor

- Highly durable 17" POS grade
- PCAP touch (like iPad® screen)
- Integrated barcode scanner and speakers, on-screen keyboard frees up bench space
- Secure, integrated and flexible mounting left or right of the Alpaca
- Improves workflow, efficiency and visibility of information







ALPACA SPECIFICATIONS





Product Name	Blister Packing Machine
Model No.	YS-BLIP-1
Dispensing Speed	60sec/pack (1type1pill/cell)
Material of Blister	Polyester
Canisters	Large x 6pcs, Regular x 54pcs
Dimensions	W890 x D645 x H2170 (mm)
Weight	Approx 230kg (not including canisters)
Power Consumption	500VA (MAX)
Power Supply	AC240V 50Hz
Manual Pill Tray	28 cells
Alarm	Typing tone and error sounds
Pill Sensor Type	Optical sensor

Blisters

The blisters have been redesigned to increase volume but more importantly to make it easier for pharmacists to check the contents of each pottle therefore delivering safer healthcare outcomes to our patients.

Blister	24mm	18mm	12mm	6mm
Alpaca	14.1	11.4	8	4.2
Medico	9.6	7.2	5	2.6
Difference	4.5	4.2	3	1.6
Percentage	47%	58%	60%	62%





Country Contacts

New Zealand

Regan Cooper

Sales Manager

AKL West, North & Northland

M +64 21 950 773

E reganc@douglas.co.nz

Angela Ransley

Territory Manager

Central & Lower North Island

M +64 21 988 870

E angier@douglas.co.nz

Penny Thompson

Territory Manager

Auckland, Waikato & Bay of Plenty

M +64 21 304 992

E pennyt@douglas.co.nz

Gail Durry

Territory Manager

South Island

M +64 21 327 404

E gaild@douglas.co.nz

Australia

T +61 3 902 07010

Katherine Douglas

Douglas Automation Manager

M +61 450 989 464

E katherined@douglas.com.au

Help Desk

NZ 0800 TOAUTOMATE

0800 862 886

AUS 1800 0DOUGLAS

1800 036 84527



www.douglasautomation.com